




CLONE TENT

1.2M HIGH 1.2 x 0.6M

4136







INSTRUCTION MANUAL



WHAT'S IN THE BOX

Please take the time, before assembling tent, to make sure all contents are present within this box.

8		8		A	111.5cm
8		8		B	53cm
2		12		C	33cm
8		8		E	60.5cm
1					



seaHawk TENT KEY			
	ZIPPER DOOR/ ACCESS		OUTLET VENT 225 ^ø
	WINDOW		CABLE PORT 100 ^ø
	AIR INTAKE WALL		

ASSEMBLY INSTRUCTIONS

STEP 1

Construct the metal tent frame by assembling the metal poles, corners, and connectors as per diagram. **To avoid damage, it is very important to check that all the poles are pushed completely into each corner/connector/joiner. Use a rubber mallet to gently tap fittings into the poles if necessary.** Failure to do so will not only make the tent cover difficult to fit but may also stretch the seams and allow emissions of light from the functioning tent.



STEP 2

Un-zip the zipper systems all the way.

STEP 3

Starting with the tent's floor, snugly fit the tent cover onto the four corners of the metal frame's base. Be sure that the orientation of the cover is correct. The front door opens from the bottom to the top (**Refer PIC B**).




STEP 4

Slip the left and right hand sides of the cover over the metal frame and zip the cover up little by little while doing so (**Refer PIC B**).

STEP 5

Assemble four steel wired racks with three hanging bars onto each of the two levels of the frame. Use caution so as to not damage tent cover while fitting the racks. Slightly adjust hanging bars and racks to be flat and horizontal to each layer of the tent frame (**Refer PIC C**). The extra two hanging bars are for the top of the frame, to hang lights from.



STEP 6

Attach waterproof floor tray in place and nylon fabric straps. Zip up the zipper on the front (**Refer PIC D**).



DISMANTLING OF SMART TENT

- 1 Ensure the tent is clean and dry before dismantling.
- 2 Reverse the operation as per above instruction. (**Step 6 > Step 5 > Step 4 > Step 3 > Step 2 > Step 1**) To ensure your **Smart Tent** maintains the same "lightproof" quality, always dismantle carefully and avoid stretching the seams of the tent cover.



seaHawk is distributed in Australia by Holland Forge PTY LTD.

